

PERFECT SET-UP



SOFTSIDE INSTALLATION

TASSO®
beds



TASSO.COM



Cleanliness and Caution!

Before Set-up:

First unload water-core and safety-liner in order to warm up to room-temperature during furniture construction, otherwise danger of cracks or condensation!

Read and follow all other specific instructions very carefully. [This is an overview](#)



1. Pedestal Frame

put corners and screw them together **01**, adjust exactly, pay attention to proper overhang **02**.

2. Pedestal-Crosses

put in place and adjust **03**.



3. Base - Decking

put on precisely, pay attention to proper overhang **04**. Clean pedestal before installing watermattress **05**.





Trashbag-use

one of the packing-bags is ideal for using it as trashbag for all other packing-materials, in order to put them away and collect centrally, for example at the door handle.



4. Ground of Textile - Liner

spread out and adjust **06**.
ATTENTION: Zipper has to be closed at the bed-end, in order to reach the waterbed valve easily for inserting careproducts later.



5. Foam-Frame

put on and unpack **07**, and put into the corners of the textile-liner-ground exactly.



6. Heating-Installation

unscrew cord **08**, lead it through the cuts at the headend, tight **09** and place the heating at the lower third of the bed, no cord-loops **10**, lead out operating-cord and controller under the furniture **without crimping danger** **11**. Do not connect the heating to power before the mattress is filled!



7. Safety-Liner

pull the safety-liner over the foam-frame **12**, express the corners well **13** and put into the frame corners precisely **14**. Close the connecting-zipper to the textile-groundliner carefully, pay attention to **15** - **17**, push in Zipper-Ends **18**.

8. Duo-Divider

(being dropped at Uno) place centrally **19**, let the little valve at divider **20** open. Close it after approx. 24 hours. Don't blow air in it.





9. Water - Cores

lay out **21**, open the locks carefully **22** - **23**, lay down both caps in range at the border **24**, let the vacuum spread out. Adjust corners carefully into the corners **25** - **27**. Fill in Conditioner into the water-cores, one for each, for small UNO one, for DUAL and big UNO's wider than 160 cm two! **28** - **29**.



10. Filling

Lay out a clean! filling-hose (separate emptying-hose! -Cleaness! Germinating-danger!), avoid bends **30** - **31**, shift the hose approx. 1 meter carefully into the mattress (above the wave-motion-control-float) **32**, ATTENTION:



do not damage the fiber by hose!

Fill with warm, clean drinking-water in room-tmeperature **33** in order to avoid condensation-water (Stinker, smell).

Important after a filling-level approx. 2,5 cm: adjust the water-core finally from below! **34** corners and edges.

Don't forget to connect the heating-system to power!

Rule-of-Thumb for Filling:

DUAL: handedge-width (8-10mm)

UNO = 5mm below the bolster-farme-border.

Remove the hose dropfree after filling **35**, empty hose by rolling up! **36**.

11. Ventilate

attach air extractor-pump, hold up the valve **37**, and stroke the air-bubbles with an arm towards the valve. **38**.



This procedure needs to be repeated a few days later. Put the valve deep into the water during closing **39**, in order to avoid air-entrance! Put the label over the valve **40** (dirt-barrier). Notice the Conditioner-additions every year on the label.

