

Sport-Thieme Folien-Wasserrutschbahn

Vielen Dank, dass Sie sich für ein Sport-Thieme Produkt entschieden haben!


Damit Sie viel Freude an diesem Gerät haben und die Sicherheit gewährleistet ist, sollten Sie diese Anleitung zunächst vollständig durchlesen, bevor Sie mit der Montage beginnen.

Für Fragen und Wünsche stehen wir Ihnen gerne zur Verfügung.



1. Bitte überprüfen Sie die Lieferung auf Vollständigkeit:

- ① 1 x Plane 6 x 1,10 m
- ② 1 x Wasserschlauch 1/2"-Anschluss
- ③ 6 x Befestigungsclip
- ④ 6 x Hering
- ⑤ 6 x Gummiseil für Befestigungsclip
- ⑥ 1 x Schlauchübergangsstück (graue Markierung)
- ⑦ 1 x Wasserstop 1/2"



2. Allgemein

Mit der Rutsche kann man herrlich auf dem Rasen herumtoben. Gerade wenn es draußen heiß ist kommt die Rutsche wie gerufen. Jedes Kind planscht gerne mit Wasser und wird voller Begeisterung auf dem langen Wasserteppich entlanggleiten.

Die Rutsche ist aus reißfester Folie und hat einen 1/2"-Anschluss zur Berieselung.

Sie ist 6 m lang und 1,10 m breit.

Die 2,5 mm starke Folie ist sehr robust und ermöglicht so unbeschwertem Rutschspaß.




Abb. 1 : Ansicht

3. Aufbauanleitung

Die Rutschplane an geeigneter Stelle auslegen (leicht abschüssige Wiese). Dabei muss beachtet werden, dass ein Sicherheitsabstand von 5 m als Auslauf am Ende der Plane gewährleistet ist. Um Verletzungen und ein Reißen der Plane vorzubeugen muss außerdem kontrolliert werden, dass keine spitzen Gegenstände wie Glasscherben, Nägel u.a. unter der Planfläche liegen.

Als nächstes den Schlauch durch die Löcher am oberen Ende der Plane fädeln. Die Löcher im Schlauch müssen in Richtung der Plane zeigen.

An einem Ende des Schlauches bitte den Wasserstop anbringen. An der anderen Seite wird das Schlauchübergangsstück montiert. Hier erfolgt der Anschluss von Ihrem Wasserschlauch.

Den Befestigungsclip wie in Abb.3 dargestellt zusammenfügen.

Nun die Gummiseile an die Befestigungsclips binden und diese wie in der Abbildung ① zu sehen ist an der Plane befestigen.

Als letztes noch die Heringe durch die Gummiseile stecken und die Plane straff fixieren, so dass sie glatt auf dem Boden liegt.

Dieses Gerät wurde nur für den bestimmungsgemäßen Gebrauch konstruiert

Achtung: Das Gerät nicht überlasten oder beklettern!



Abb. 3 : Befestigungsclip

Wartungshinweise und Pflege

Hinweis: Führen Sie in regelmäßigen Abständen eine Sichtprüfung durch. Aufgrund unserer kontinuierlichen Qualitätsprüfung der Produkte können sich technische Änderungen ergeben, die zu geringfügigen Abweichungen in der Anleitung führen kann. Prüfen Sie das Gerät auf eventuelle Beschädigungen, und tauschen Sie verschlissene Teile aus.


Für Fragen stehen wir Ihnen gerne zu Verfügung.

Ihr Sport-Thieme Team

Sport-Thieme Water Slide

Thank you very much for choosing a Sport-Thieme product!

Please read the instructions fully before you assemble the equipment, so you can enjoy the product and safety is guaranteed. We are happy to answer any questions you may have.



Please check that all parts are present:

- ① 1 tarpaulin sheet, 6×1.10 m
- ② 1 sprinkler connection, 1/2-inch
- ③ 6 attachment clips
- ④ 6 pegs
- ⑤ 6 bungees for attachment clip
- ⑥ 1 hose connector (grey marking)
- ⑦ 1 water stopper (red marking), 1/2-inch




Figure 2: Individual parts

1. General

The slide is a great product for children to have fun with in the garden, particularly when it's hot. Every child loves splashing with water and will enjoy sliding on the grass.

The slide is made up of a tear-resistant tarpaulin sheet and features a 1/2-inch sprinkler connection. It is 6 m long and 1.10 m wide. The 2.5-mm-thick sheet is extremely hard-wearing, so children can splash and slide to their heart's content.




Abb. 1 : Ansicht

Figure 1: Overview

2. Assembly instructions

Spread the tarpaulin slide out in a suitable location (a lawn with a slight slope would be ideal). Please ensure there is a safety distance of 5 m at the bottom of the slide. To prevent any user injuries or damage to the tarpaulin sheet, check that there are no sharp objects (such as broken glass, nails, etc.) underneath the sheet.

Insert the sprinkler connection into the loops at the top of the slide. The holes in the sprinkler connection must point towards the slide.

Attach the water stopper to one end of the sprinkler connection and the hose connector to the other. This is where you will attach a water hose. Assemble the attachment clip as shown in figure 3.

Then tie the bungees to the attachment clips and secure them to the slide as shown in figure 1.

Finally, put the pegs through the bungees and anchor the slide so it is taut and level with the ground.

This product must only be used for its intended purpose.



Figure 3: Attachment clip

3. Maintenance and care

Caution!

Do not overload or climb on this equipment!

Please note:

- Perform a visual inspection at regular intervals.
- Due to continuous quality control of our products, technical changes may occur which could lead to minor alterations to the instructions.
- Check the equipment for any damage and replace worn parts.

If you have any questions,

our experts at Sport-Thieme are here for you.