

Sport-Thieme Fehlstartleine

Vielen Dank, dass Sie sich für dieses Produkt entschieden haben!

Damit Sie viel Freude an diesem Produkt haben und die Sicherheit gewährleistet ist, sollten Sie diese Anleitung vor dem Gebrauch zunächst vollständig durchlesen. Bewahren Sie die Anleitung gut auf. Für Fragen und Wünsche stehen wir Ihnen gerne zur Verfügung.



Funktion und Einsatz

Eine Fehlstartleine ist eine spezielle Sicherheits- und Signaleinrichtung, die bei Schwimmwettkämpfen eingesetzt wird, um einen Fehlstart eindeutig anzuzeigen. Wird ein Fehlstart festgestellt, wird die Leine ausgelöst und herabgelassen. Gleichzeitig ertönt ein akustisches Signal, das den Schwimmern den sofortigen Abbruch signalisiert. Anschließend werden die Athleten zum Startblock zurückgerufen und der Startvorgang erneut durchgeführt.

Installation

Die Fehlstartleine wird quer über das Schwimmbecken gespannt und entsprechend den geltenden Wettkampfbestimmungen positioniert. Je nach Regelwerk muss sie in einer definierten Höhe über dem Wasserspiegel (z. B. 1,20 m) sowie in einer festgelegten Entfernung zum Startblock montiert werden.

Auslösung im Falle eines Fehlstarts

Startet ein Schwimmer vor dem offiziellen Startsignal, löst der Schiedsrichter ein Fehlstartsignal aus – in der Regel ein Pfiff oder ein akustisches Warnsignal. Daraufhin wird die Leine mechanisch oder elektrisch herabgelassen.

Abbruch des Rennens

Die herabgelassene Fehlstartleine dient als sofortiges visuelles Signal für alle Schwimmer, dass der Start ungültig war und das Rennen unverzüglich beendet werden muss.

Wiederaufnahme des Startvorgangs

Nach dem Abbruch werden die Schwimmer zurückgerufen und der Start wiederholt.

Sport-Thieme False Start Line

Thank you for choosing this product!

Please read the following notes carefully before use so you can enjoy this product safely and keep these instructions for future reference. If you have any questions, our team is here for you.



Purpose and Use in Competitive Swimming

A false start line is a specialized safety and signaling device used in swimming competitions to clearly indicate a false start. If a false start is detected, the line is released and lowered. At the same time, an audible signal sounds to immediately alert the swimmers to stop. Afterwards, the athletes are called back to the starting blocks and the start procedure is repeated.

Installation

The false start line is stretched across the pool and positioned according to applicable competition regulations. Depending on the rulebook, it must be installed at a defined height above the water surface (e.g., 1.20 m) and at a specified distance from the starting block.

Activation in the event of a false start

If a swimmer starts before the official starting signal, the referee triggers a false start signal, usually a whistle or an audible warning. The line is then lowered mechanically or electrically.

Race interruption

The lowered false start line serves as an immediate visual signal to all swimmers that the start was invalid and the race must be stopped without delay.

Restarting the procedure

After the interruption, the swimmers are recalled and the start is repeated.