

Sport-Thieme® Original “Competition” Swimming Line

These swimming lines are made to your specifications. For a maximum lifespan, we recommend that you store your swimming lines on a transport trolley.

If stored outside, we recommend using a cover.

Tension the lines until they sit in a straight line on the surface of the water. Do not over-tighten the lines.

All parts can be ordered separately

1. Use the tensioning spring to attach side 1 to a pre-existing attaching point.
2. Unlock side 2 with the turnbuckle and attach the lock to the pre-existing attaching point on the opposite side.
3. Use the wrench (included) to tension the turnbuckle.
4. Tension the line until it sits in a straight line on the surface of the water.

Do not over-tighten the

line (steel line should still have approx. 5 cm give when pushed down into the water)!

Please note that over-tensioning can cause damage!



Sport-Thieme Original “Competition” Swimming Line Turnbuckle

- To loosen, the wrench must be placed onto the 6-edge bolt
- Use the wrench to release the latch
- With the latch released, the drum can now be turned

Please do not hit the latch with the wrench (or anything similar).

Hitting causes the tension spring to bend and the guarantee will be void.

